

Maintenance Manual MM-0467

DiscPlus™ EX225 Air Disc Brake

Revised 02-13



Service Notes

About This Manual

This manual provides installation and maintenance procedures for the DiscPlus™ EX225 air disc brake.

Before You Begin

1. Read and understand all instructions and procedures before you begin to service components.
2. Read and observe all Warning and Caution hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.
3. Follow your company's maintenance and service, installation, and diagnostics guidelines.
4. Use special tools when required to help avoid serious personal injury and damage to components.

Hazard Alert Messages and Torque Symbols

WARNING

A Warning alerts you to an instruction or procedure that you must follow exactly to avoid serious personal injury and damage to components.

CAUTION

A Caution alerts you to an instruction or procedure that you must follow exactly to avoid damage to components.

 This symbol alerts you to tighten fasteners to a specified torque value.

How to Obtain Additional Maintenance and Service Information

Visit Literature on Demand on meritor.com to access and order additional information.

Contact the OnTrac Customer Service Center at 866-668-7221 (United States and Canada); 001-800-889-1834 (Mexico); or email OnTrac@meritor.com.

If Tools and Supplies are Specified in This Manual

Contact Meritor's Commercial Vehicle Aftermarket 888-725-9355.

Information contained in this publication was in effect at the time the publication was approved for printing and is subject to change without notice or liability. Meritor Heavy Vehicle Systems, LLC, reserves the right to revise the information presented or to discontinue the production of parts described at any time.

pg. i	Asbestos and Non-Asbestos Fibers		
1	Section 1: Exploded Views		
	DiscPlus™ EX225 Air Disc Brake		
2	Hub and Rotor Assembly		
3	Caliper Sectional View		
4	Adjuster Sectional View		
5	Section 2: Introduction		
	Description		
	Operation		
	Automatic Adjustment		
	Operation Without Adjustment		
6	Operation with Adjustment		
	Manual Adjustment and Deadadjustment During a Pad Change		
7	Section 3: Roadside Inspection		
	Intervals		
	Procedures		
	Inspection Procedure		
	Caliper Adjustment		
	Lining Wear		
8	Rotor		
	Air Chamber		
9	Section 4: Caliper Assembly and Brake Pad		
	Inspection		
	Caliper		
	Brake Deadadjustment Procedure		
10	Brake Adjustment Inspection		
	Brake Pad Removal and Inspection		
13	Check Slide Pin Bushing Wear		
14	Brake Pad Installation		
16	Set the Initial Brake Pad-to-Rotor Running Clearance		
17	Section 5: Caliper Components Replacement		
	Introduction		
	Remove the Caliper Assembly		
18	Install the Caliper Assembly		
19	Replace the Adjuster Cover		
	Replace the Piston Boots		
22	Remove the Caliper Bridge		
23	Remove the Caliper Housing Assembly		
	Remove the Slide Pin Boots		
24	Remove the Slide Pin Bushings		
26	Install the Slide Pin Bushings		
28	Replace the Slide Pins		
29	Install the Slide Pin Boots		
	Install the Caliper Housing Assembly		
31	Install the Caliper Bridge		
pg. 33	Section 6: Rotor		
	Inspection		
	Cracks		
	Heat Checking		
34	Light Heat Checking		
	Heavy Heat Checking		
	Deep Grooves or Scores		
	Blue Marks or Bands		
35	Measure the Rotor Thickness		
	Measure the Rotor Runout		
36	Removal and Installation		
	Replace the Rotor		
37	Section 7: Air Chamber		
	Introduction		
	Inspection		
38	Installation		
	Spring or Service Brake Chamber		
40	Section 8: Specifications		
	Lining Wear Limits		
	Torque Specifications		
42	Section 9: Diagnostics		
	Troubleshooting		
44	Section 10: Special Tools		
	MST 1000, Bushing Service Tool		
45	MST225 5001, ADB225 Wrench (Extension Adapter)		

Asbestos and Non-Asbestos Fibers

ASBESTOS FIBERS WARNING

The following procedures for servicing brakes are recommended to reduce exposure to asbestos fiber dust, a cancer and lung disease hazard. Material Safety Data Sheets are available from Meritor.

Hazard Summary

Because some brake linings contain asbestos, workers who service brakes must understand the potential hazards of asbestos and precautions for reducing risks. Exposure to airborne asbestos dust can cause serious and possibly fatal diseases, including asbestosis (a chronic lung disease) and cancer, principally lung cancer and mesothelioma (a cancer of the lining of the chest or abdominal cavities). Some studies show that the risk of lung cancer among persons who smoke and who are exposed to asbestos is much greater than the risk for non-smokers. Symptoms of these diseases may not become apparent for 15, 20 or more years after the first exposure to asbestos.

Accordingly, workers must use caution to avoid creating and breathing dust when servicing brakes. Specific recommended work practices for reducing exposure to asbestos dust follow. Consult your employer for more details.

Recommended Work Practices

1. **Separate Work Areas.** Whenever feasible, service brakes in a separate area away from other operations to reduce risks to unprotected persons. OSHA has set a maximum allowable level of exposure for asbestos of 0.1 f/cc as an 8-hour time-weighted average and 1.0 f/cc averaged over a 30-minute period. Scientists disagree, however, to what extent adherence to the maximum allowable exposure levels will eliminate the risk of disease that can result from inhaling asbestos dust. OSHA requires that the following sign be posted at the entrance to areas where exposures exceed either of the maximum allowable levels:

**DANGER: ASBESTOS
CANCER AND LUNG DISEASE HAZARD
AUTHORIZED PERSONNEL ONLY
RESPIRATORS AND PROTECTIVE CLOTHING
ARE REQUIRED IN THIS AREA.**

2. **Respiratory Protection.** Wear a respirator equipped with a high-efficiency (HEPA) filter approved by NIOSH or MSHA for use with asbestos at all times when servicing brakes, beginning with the removal of the wheels.
3. **Procedures for Servicing Brakes.**
- Enclose the brake assembly within a negative pressure enclosure. The enclosure should be equipped with a HEPA vacuum and worker arm sleeves. With the enclosure in place, use the HEPA vacuum to loosen and vacuum residue from the brake parts.
 - As an alternative procedure, use a catch basin with water and a biodegradable, non-phosphate, water-based detergent to wash the brake drum or rotor and other brake parts. The solution should be applied with low pressure to prevent dust from becoming airborne. Allow the solution to flow between the brake drum and the brake support or the brake rotor and caliper. The wheel hub and brake assembly components should be thoroughly wetted to suppress dust before the brake shoes or brake pads are removed. Wipe the brake parts clean with a cloth.
 - If an enclosed vacuum system or brake washing equipment is not available, employers may adopt their own written procedures for servicing brakes, provided that the exposure levels associated with the employer's procedures do not exceed the levels associated with the enclosed vacuum system or brake washing equipment. Consult OSHA regulations for more details.
 - Wear a respirator equipped with a HEPA filter approved by NIOSH or MSHA for use with asbestos when grinding or machining brake linings. In addition, do such work in an area with a local exhaust ventilation system equipped with a HEPA filter.
 - NEVER** use compressed air by itself, dry brushing, or a vacuum not equipped with a HEPA filter when cleaning brake parts or assemblies. **NEVER** use carcinogenic solvents, flammable solvents, or solvents that can damage brake components as wetting agents.
4. **Cleaning Work Areas.** Clean work areas with a vacuum equipped with a HEPA filter or by wet wiping. **NEVER** use compressed air or dry sweeping to clean work areas. When you empty vacuum cleaners and handle used rags, wear a respirator equipped with a HEPA filter approved by NIOSH or MSHA for use with asbestos. When you replace a HEPA filter, wet the filter with a fine mist of water and dispose of the used filter with care.
5. **Worker Clean-Up.** After servicing brakes, wash your hands before you eat, drink or smoke. Shower after work. Do not wear work clothes home. Use a vacuum equipped with a HEPA filter to vacuum work clothes after they are worn. Launder them separately. Do not shake or use compressed air to remove dust from work clothes.
6. **Waste Disposal.** Dispose of discarded linings, used rags, cloths and HEPA filters with care, such as in sealed plastic bags. Consult applicable EPA, state and local regulations on waste disposal.

Regulatory Guidance

References to OSHA, NIOSH, MSHA, and EPA, which are regulatory agencies in the United States, are made to provide further guidance to employers and workers employed within the United States. Employers and workers employed outside of the United States should consult the regulations that apply to them for further guidance.

NON-ASBESTOS FIBERS WARNING

The following procedures for servicing brakes are recommended to reduce exposure to non-asbestos fiber dust, a cancer and lung disease hazard. Material Safety Data Sheets are available from Meritor.

Hazard Summary

Most recently manufactured brake linings do not contain asbestos fibers. These brake linings may contain one or more of a variety of ingredients, including glass fibers, mineral wool, aramid fibers, ceramic fibers and silica that can present health risks if inhaled. Scientists disagree on the extent of the risks from exposure to these substances. Nonetheless, exposure to silica dust can cause silicosis, a non-cancerous lung disease. Silicosis gradually reduces lung capacity and efficiency and can result in serious breathing difficulty. Some scientists believe other types of non-asbestos fibers, when inhaled, can cause similar diseases of the lung. In addition, silica dust and ceramic fiber dust are known to the State of California to cause lung cancer. U.S. and international agencies have also determined that dust from mineral wool, ceramic fibers and silica are potential causes of cancer.

Accordingly, workers must use caution to avoid creating and breathing dust when servicing brakes. Specific recommended work practices for reducing exposure to non-asbestos dust follow. Consult your employer for more details.

Recommended Work Practices

1. **Separate Work Areas.** Whenever feasible, service brakes in a separate area away from other operations to reduce risks to unprotected persons.
2. **Respiratory Protection.** OSHA has set a maximum allowable level of exposure for silica of 0.1 mg/m³ as an 8-hour time-weighted average. Some manufacturers of non-asbestos brake linings recommend that exposures to other ingredients found in non-asbestos brake linings be kept below 1.0 f/cc as an 8-hour time-weighted average. Scientists disagree, however, to what extent adherence to these maximum allowable exposure levels will eliminate the risk of disease that can result from inhaling non-asbestos dust.


Therefore, wear respiratory protection at all times during brake servicing, beginning with the removal of the wheels. Wear a respirator equipped with a high-efficiency (HEPA) filter approved by NIOSH or MSHA, if the exposure levels may exceed OSHA or manufacturers' recommended maximum levels. Even when exposures are expected to be within the maximum allowable levels, wearing such a respirator at all times during brake servicing will help minimize exposure.

3. **Procedures for Servicing Brakes.**
- Enclose the brake assembly within a negative pressure enclosure. The enclosure should be equipped with a HEPA vacuum and worker arm sleeves. With the enclosure in place, use the HEPA vacuum to loosen and vacuum residue from the brake parts.
 - As an alternative procedure, use a catch basin with water and a biodegradable, non-phosphate, water-based detergent to wash the brake drum or rotor and other brake parts. The solution should be applied with low pressure to prevent dust from becoming airborne. Allow the solution to flow between the brake drum and the brake support or the brake rotor and caliper. The wheel hub and brake assembly components should be thoroughly wetted to suppress dust before the brake shoes or brake pads are removed. Wipe the brake parts clean with a cloth.
 - If an enclosed vacuum system or brake washing equipment is not available, carefully clean the brake parts in the open air. Wet the parts with a solution applied with a pump-spray bottle that creates a fine mist. Use a solution containing water, and, if available, a biodegradable, non-phosphate, water-based detergent. The wheel hub and brake assembly components should be thoroughly wetted to suppress dust before the brake shoes or brake pads are removed. Wipe the brake parts clean with a cloth.
 - Wear a respirator equipped with a HEPA filter approved by NIOSH or MSHA when grinding or machining brake linings. In addition, do such work in an area with a local exhaust ventilation system equipped with a HEPA filter.
 - NEVER** use compressed air by itself, dry brushing, or a vacuum not equipped with a HEPA filter when cleaning brake parts or assemblies. **NEVER** use carcinogenic solvents, flammable solvents, or solvents that can damage brake components as wetting agents.
4. **Cleaning Work Areas.** Clean work areas with a vacuum equipped with a HEPA filter or by wet wiping. **NEVER** use compressed air or dry sweeping to clean work areas. When you empty vacuum cleaners and handle used rags, wear a respirator equipped with a HEPA filter approved by NIOSH or MSHA, to minimize exposure. When you replace a HEPA filter, wet the filter with a fine mist of water and dispose of the used filter with care.
5. **Worker Clean-Up.** After servicing brakes, wash your hands before you eat, drink or smoke. Shower after work. Do not wear work clothes home. Use a vacuum equipped with a HEPA filter to vacuum work clothes after they are worn. Launder them separately. Do not shake or use compressed air to remove dust from work clothes.
6. **Waste Disposal.** Dispose of discarded linings, used rags, cloths and HEPA filters with care, such as in sealed plastic bags. Consult applicable EPA, state and local regulations on waste disposal.

Regulatory Guidance

References to OSHA, NIOSH, MSHA, and EPA, which are regulatory agencies in the United States, are made to provide further guidance to employers and workers employed within the United States. Employers and workers employed outside of the United States should consult the regulations that apply to them for further guidance.

DiscPlus™ EX225 Air Disc Brake




4005030b

Item	Description
1	Air Chamber
2	Slide Pin Cap (2)
3	Short Slide Pin Bolt
4	Short Slide Pin
5	Bridge Bolt (4)
6a	Caliper Housing Assembly — Axial Chamber Mount
6b	Caliper Housing Assembly — Radial Chamber Mount
7	Slide Pin Boot (2)
8	Visual Wear Indicator Spring
9	Pad Retainer
10	Pad Retainer Bolt
11	Adjuster Cover
12	Long Slide Pin Bolt
13	Long Slide Pin

Item	Description
14	Piston Boot (2)
15	Air Chamber Washer (2)
16	Air Chamber Nut (2)
17	Visual Wear Indicator
18	Bridge
19	Carrier Bolt — EX225L (4), EX225H (5-6)
20	Washer — EX225L (4), EX225H (5-6)
21a	Torque Plate — Axial Mount
21b	Torque Plate — Radial Mount
22a	Carrier — Axial Mount
22b	Carrier — Radial Mount
23	Brake Pad (2)
24	Pad Spring (2)

1 Exploded Views


Hub and Rotor Assembly



4005031a

Item	Description
1	Hub-to-Rotor Bolt
2	Washer
3	Hub Assembly
4	Rotor

Caliper Sectional View




4005032a

Item	Description
1	Short Slide Pin Oval Bushing
2	Housing Seal
3	Operating Shaft
4	Return Spring
5	Piston
6	Piston Head
7	Chamber Piston
8	Adjuster Shaft
9	Half Bearing
10	Roller
11	Tappet

Item	Description
12	Adjuster Stem
13	Long Slide Pin Bushing

1 Exploded Views

Adjuster Sectional View



4005033a

Item	Description
1	Clutch Pack
2	Outer Drive Sleeve
3	Inner Drive Sleeve
4	Unidirectional Friction Spring
5	Intermediate Gear
6	Adjuster Shaft
7	Drive Pin
8	Operating Shaft
9	Tappet
10	Piston

Item	Description
11	Adjuster Housing
12	Adjuster Stem
13	Adjuster Cover

Description

The EX225 air-actuated disc brake has a direct-mounted air chamber. Figure 2.1. The brake can be installed onto any axle and can be used for vehicle parking when it is equipped with a service spring brake chamber. The basic operation of the brake is simple, but it is important that the features of the load insensitive automatic adjuster are clearly understood. It is essential that the correct service procedures be observed to ensure that the brake gives satisfactory service throughout its working life.




Figure 2.1

Operation

The air chamber is attached to the caliper housing and operates directly onto the internal operating shaft assembly. Seals in the housing and chamber assemblies provide sealing between the air chamber and housing. The carrier is mounted to the vehicle. It straddles the rotor and supports the brake pads. The housing assembly slides on two fully sealed slide pins which are bolted to the brake carrier. As the pads wear, adjustment takes place automatically and independently of load. Load independent means adjustment takes place under very small clamping forces only, therefore preventing over adjustment and minimizing air consumption.

Two slide pins are attached to the brake carrier by slide pin bolts. The brake carrier is connected to the axle through the use of the torque plate. The caliper housing assembly is mounted so that it floats on the slide pins. A bridge is attached to the caliper housing assembly to provide the reaction force on the outboard pad.

The caliper housing and bridge slide on bushings that are pressed into the caliper housing assembly. On the short slide pin side, the bushing is oval to accommodate brake deflection during braking. On the long slide pin side, the bushings are round and provide a more positive location for the housing. The slide pins are sealed externally by slide pin boots and slide pin caps.

The force introduced from the air chamber is amplified by the geometry of the operating shaft. This clamping force is transferred to the inboard pad through the half-bearings, rollers, tappets, pistons and piston heads. Once the inboard pad has been applied, the force of reaction acting through the floating caliper housing assembly and bridge pulls the outboard pad onto the brake rotor. The forces created by the friction of the brake pads on the brake rotor are transferred at the ends of the pads onto the carrier, which is rigidly mounted to the axle.

The brakes are released by reducing the input force on the operating shaft, thus reducing the clamp force of the brake. The return spring then returns the clamping mechanism and the operating shaft back to their starting position, leaving the pads with a defined running clearance to the rotor. The small runout of the brake rotor and hub-bearing clearances will then generate a small clearance for the outboard pad through only a few revolutions of the rotor.

Automatic Adjustment

The automatic adjuster adjusts the brake pad clearance to compensate for pad wear. Every time the brake is applied, the system senses whether adjustment is required or whether the running clearance of the brake pads to the brake rotor is still within the built-in tolerance and does not need to be adjusted. The built-in tolerance is determined in the design by the clearance between the ball-ended drive pin that is rigidly fixed to the operating shaft and the fork on the end of the adjuster shaft.

Operation Without Adjustment

From the rest position, the air chamber push rod moves FORWARD, rotating the operating shaft. When the pistons move FORWARD through the built-in running clearance, the ball-ended drive pin starts to contact the driving side of the fork on the end of the adjuster shaft. Further movement of the air chamber push rod

2 Introduction

rotates the operating shaft, causing the adjuster shaft to rotate because the built-in clearance has been taken up. The outer drive sleeve is fixed to the adjuster shaft and rotates the inner drive sleeve through the clutch pack. The inner drive sleeve is linked to the intermediate gear by a unidirectional friction spring and this tries to rotate the tappets. However, the friction in the threads of the tappets and pistons increases due to the clamping force on the pads. This prevents the pistons and tappets from rotating relative to one another. The pistons cannot rotate in the adjuster housing, and due to the high torque to turn the tappets, the clutch pack slips, preventing adjustment of the mechanism below the correct running clearance.

Operation with Adjustment

When the running clearance is greater than the built-in tolerance as a result of pad or rotor wear, adjustment is required. From the rest position, the push rod of the air chamber moves FORWARD, rotating the operating shaft. As the pistons move FORWARD beyond the built-in running clearance, the ball-ended drive pin starts to contact the driving side of the fork on the end of the adjuster shaft. Further operating shaft movement causes rotation of the adjuster shaft through the ball-ended drive pin.

Driving through the clutch plates and the unidirectional friction spring, the intermediate gear rotates. Due to the excessive running clearance, the tappets now rotate in the pistons. The pistons cannot rotate and are wound out from their housing. When the pads contact the rotor, the clamping force increases the thread friction in the tappets and pistons. The torque to turn the tappets increases and the clutch pack driving the intermediate gear starts to slip, preventing further adjustment. The adjustment is not wound back during the return of the actuation mechanism. As the operating shaft returns to the brake's off position, the ball-ended drive pin travels back through the clearance in the fork on the end of the adjuster shaft. Once this clearance is taken up, the adjuster shaft rotates in the reverse direction, rotating the inner drive sleeve through the clutch pack. However, in this direction, the unidirectional friction spring cannot drive the intermediate gear, leaving the tappets and intermediate gear in the adjusted state. The system is in its starting position.

Manual Adjustment and Deadadjustment During a Pad Change

Manual adjustment of the brake must only be made at a pad change. No manual intervention is required between pad changes.

A manual adjuster stem runs in constant mesh with the gear form on the outside of the tappets. The end of this stem comes out from the brake housing through a seal and is protected by an adjuster cover.

The automatic adjuster maintains a nominal pad-to-rotor clearance of 0.030-inch (0.75 mm).

Refer to Section 4 for adjustment and deadadjustment procedures.

Intervals

For military on/off highway and military severe duty applications, refer to TP-10109. For a copy of this technical bulletin, contact the OnTrac Customer Service Center at 866-OnTrac1 (688-7221).

Periodically inspect the brakes. Check the caliper, torque plate, pads and rotor for signs of wear and damage. Also check for any loose or missing screws. Use the schedule below that gives the most frequent inspections. For additional roadside inspection information, contact the OnTrac Customer Service Center at 866-OnTrac1 (688-7221).

- Fleet chassis lubrication schedule
- Chassis manufacturer lubrication schedule
- At least four times during lining life
- At tire replacement

Procedures

WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving. Support the vehicle with safety stands. Do not work under a vehicle supported only by jacks. Jacks can slip and fall over. Serious personal injury and damage to components can result.

1. Wear safe eye protection. Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving.
2. With the wheels on, check the following conditions.

Inspection Procedure

Caliper Adjustment

1. Attach a dial indicator to the torque plate or axle frame. The dial indicator reading should be taken from the most central part on the brake. Figure 3.1.




Figure 3.1

2. Check the brake adjustment by sliding the caliper back and forth, by hand, along the slide pins.
 - **If the caliper slides more than 0.08-inch (2 mm):** The brake is out-of-adjustment and requires further inspection or replacement.

Lining Wear

The EX225 air disc brake can use a variety of devices to monitor pad wear.

- A visual wear indicator (VWI), Figure 3.2.
- A pad wear warning indicator (PWWI) which is fitted to the pad. Depending on the vehicle configuration, a warning signal will be given to indicate that a pad change is required. Figure 3.3.

Brake pads and the PWWI, if applicable, must be replaced when the lining thickness has worn to the values listed in Section 8.

The visual wear indicator alerts you as to when the braking system needs to be inspected for wear on the pads and rotor. Figure 3.2.

3 Roadside Inspection




Figure 3.2




Figure 3.3

When the pads are new, the end of the visual wear indicator stem will protrude past the edge of the housing casting. Figure 3.4. As the pads wear, less and less of the indicator will be visible past the edge of the casting. The increments of the indicator equate to a level of pad wear. Figure 3.5.




Figure 3.4




Figure 3.5

- **If the indicator shows more than 75% wear:** The pads require further inspection or replacement. Refer to Section 4.

Rotor

Visually inspect the rotor for signs of cracks, deep grooves, blue marks and heat checking. Refer to Section 6.

Air Chamber

Inspect the air chamber to verify that the caliper mounting bolts and air lines are securely fastened and are not damaged.

Hazard Alert Messages

Read and observe all Warning and Caution hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

⚠ WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving. Support the vehicle with safety stands. Do not work under a vehicle supported only by jacks. Jacks can slip and fall over. Serious personal injury and damage to components can result.

Before you service a spring chamber, carefully follow the manufacturer's instructions to compress and lock the spring to completely release the brake. Verify that no air pressure remains in the service chamber before you proceed. Sudden release of compressed air can cause serious personal injury and damage to components.

⚠ ASBESTOS AND NON-ASBESTOS FIBERS WARNING

Some brake linings contain asbestos fibers, a cancer and lung disease hazard. Some brake linings contain non-asbestos fibers, whose long-term effects to health are unknown. You must use caution when you handle both asbestos and non-asbestos materials.

Inspection

Caliper

1. Wear safe eye protection. Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving.
2. Apply air pressure to release the parking brake.
3. Remove all air from the air system. If the brake has spring chambers, carefully cage and lock the spring so that it cannot actuate during assembly or disassembly. Follow the chamber manufacturer's instructions to completely release the brake.
4. Use a jack to raise the vehicle so that the wheels to be serviced are off the ground. Support the vehicle with safety stands.
5. Remove the wheel and tire assembly.

⚠ WARNING

Remove dry brake dust with a vacuum brush or wipe the areas with a damp cloth. Never use an air line to blow dust from the brake and rotor area. Never try to accelerate drying time by using an air line. Serious personal injury and damage to components can result.

6. Use a vacuum brush or damp cloth to remove any dirt from the brake assembly.
7. Visually check the caliper housing, bridge and carrier for damage.
 - If there is any damage: Replace the component or caliper assembly.

Brake Deadadjustment Procedure

1. Remove the adjuster cover. Figure 4.1.




Figure 4.1

⚠ CAUTION

Always use a suitable wrench to carefully deadadjust and adjust the brake. Do not use air or power tools. Damage to components can result.

2. Use a 10 mm wrench to deadadjust the brake. Rotate the adjuster stem COUNTERCLOCKWISE until you feel the adjuster stem stop. Deadadjustment requires more force than adjustment. Do not exceed 30 lb-ft (40 N•m) in either direction. Figure 4.2 and Figure 4.3. **ⓘ**
 - If the manual adjuster does not rotate in either direction: Replace the caliper assembly and chamber assembly.

4 Caliper Assembly and Brake Pad




Figure 4.2




Figure 4.3

Brake Adjustment Inspection

⚠ CAUTION

Before you check for correct brake adjustment, verify that the wrench will not be obstructed by the air chamber, hoses or other brake or axle components. Damage to the brake can result.

1. To check for correct brake adjustment, deadadjust the brake. Use a 10 mm wrench to rotate the adjuster stem one-quarter turn COUNTERCLOCKWISE.

2. With the 10 mm wrench on the adjuster stem, actuate the brake one time. Figure 4.4.

- If the wrench rotates **CLOCKWISE** when you actuate the brake: The adjuster mechanism is working correctly.
- If the wrench does not rotate **CLOCKWISE** when you actuate the brake: The adjuster mechanism is not working correctly. Replace the caliper assembly.




Figure 4.4

Brake Pad Removal and Inspection

1. Use a 17 mm wrench to remove the pad retainer bolt. Remove the pad retainer. Figure 4.5.




Figure 4.5

2. Visually inspect the pad retainer.

4 Caliper Assembly and Brake Pad

- **If the pad retainer is bent or damaged:** Replace the pad retainer.
3. Remove the pad springs.
 - **If a PWWI is present:** Lift the PWWI assembly and disengage the tang from the housing assembly. Do not remove the plastic block sensors from their locations in the pads unless the PWWI assembly is being replaced. Always replace a damaged PWWI assembly with genuine OE parts. Figure 4.6 and Figure 4.7.




Figure 4.6




Figure 4.7

4. Remove the outboard brake pad from the caliper assembly and mark the brake pad "outboard". Figure 4.8.




Figure 4.8

5. Remove the inboard brake pad from the caliper assembly and mark the brake pad "inboard".
6. Use a vacuum brush or damp cloth to remove the dirt and dust from the carrier brake pad contact surfaces.
7. Inspect the carrier for signs of damage or wear. Pay particular attention to the pad abutments. Figure 4.9.
 - **If there is excessive wear or damage to the abutments:** It may be necessary to replace the caliper assembly.




Figure 4.9

4 Caliper Assembly and Brake Pad

⚠ CAUTION

Replace the pads on both brakes of a single axle or all four brakes of a tandem axle at the same time. If you do not replace all the pads at the same time, poor brake performance will occur.

8. Inspect the brake pads for excessive grooving or cracked friction material. Check if the friction material is loose or detached from the backing plate. If necessary, replace all the brake pad assemblies.
9. Measure the friction material thickness from the center of the brake pad. Replace brake pad assemblies before the lining thickness reaches 0.12-inch (3 mm). Figure 4.10.




Figure 4.10

10. Inspect the pad springs. Replace bent, cracked or broken pad springs.
11. Verify that the caliper slides freely, by hand, on the slide pins. Take care not to trap your fingers while you check the sliding action of the brake.
 - **If the caliper does not slide:** Check the slide pin boots for damage and verify that they are seated correctly.
12. With the pads removed, visually inspect the caliper slide pin boots and piston boots. All slide pin and piston boots should be free from damage and should be correctly seated. Figure 4.11, Figure 4.12 and Figure 4.13.
 - **If any of the piston boots or the slide pin boots are damaged or unseated:** Replace the boots.




Figure 4.11




Figure 4.12

4 Caliper Assembly and Brake Pad




Figure 4.13

Check Slide Pin Bushing Wear

Perform the following procedures with the brake assembly installed on the vehicle.

Tangential Test

1. With the pads removed, pull the caliper housing assembly OUTWARD toward the wheel flange. Attach a dial indicator so that it is in line with the centerline of the short slide pin. Attach the indicator to the hub. Figure 4.14.




Figure 4.14

2. Hold the caliper so that it cannot move. Swivel the caliper until it stops in one direction. Set the gauge to ZERO. Figure 4.14 and Figure 4.15.




Figure 4.15

3. Move the housing in the opposite direction until it stops. Figure 4.15. The maximum acceptable reading is 0.118-inch (3 mm).

- **If the reading is more than 0.118-inch (3 mm):** Replace the caliper assembly.

Radial Test

1. Attach a dial indicator onto the vehicle hub and set it against the caliper. Figure 4.16.




Figure 4.16

2. Position the brake in the half-worn pad position. This is set when a gap of approximately 0.8-inch (20 mm) exists between the rotor and bridge. Hold the caliper at the outboard pad edge and by the air chamber.

4 Caliper Assembly and Brake Pad

3. Push the brake down by hand as far as possible and set the gauge to ZERO. Figure 4.16 and Figure 4.17.




Figure 4.17

4. Pull the caliper up as far as possible without allowing the caliper to slide. The maximum acceptable reading is 0.078-inch (2 mm).
 - **If the reading is more than 0.078-inch (2 mm):** Replace the caliper assembly, or bushings and slide pins.

Brake Pad Installation

CAUTION

Install the pads with the friction material facing the rotor.
Damage to components can result.

1. If necessary, deadadjust the brakes and remove the brake pads. Refer to the procedures in this section.
2. Slide the caliper OUTWARD. Install the outboard pad and spring into the outboard side of the caliper. Figure 4.18.




Figure 4.18

3. Slide the caliper INWARD. Install the inboard pad and spring into the inboard side of the caliper. Figure 4.18.
4. Install the pad retainer and pad retainer bolt. Tighten the bolt to 25-30 lb-ft (34-40 N•m). Figure 4.19. 
 - **If you are replacing the pad retainer:** Do not use the original pad retainer bolt. Use the pad retainer bolt supplied with the kit.




Figure 4.19

4 Caliper Assembly and Brake Pad

5. If necessary, install the PWVI using one of the following procedures. The EX225 air disc brake can incorporate alternative PWVI arrangements to monitor pad wear. Refer to Figure 4.20 for Type A, Figure 4.21 for Type B and Figure 4.22 for Type C.




Figure 4.20




Figure 4.21




Figure 4.22

Type A Installation

- A. If a new PWVI is to be installed, position the pad wear cable correctly and carefully clip the pad wear warning cable retainer to the pad retaining plate.
- B. Carefully hold the pad retaining plate with the PWVI in position to allow for installation of the plastic sensor blocks. Install the plastic blocks of the PWVI into the pads. Do not use excessive force, but ensure they are pushed to the bottom of the slot.
- C. Ensure the PWVI wiring is routed over the pad backplate, away from the rotor. Figure 4.23.




Figure 4.23

Type B and Type C Installation

- A. Install the plastic blocks of the PWVI into the pads. Do not use excessive force, but ensure they are pushed to the bottom of the slot. Figure 4.23.
- B. Position the PWVI assembly into the brake and engage the tang into the housing. Figure 4.24.

4 Caliper Assembly and Brake Pad




Figure 4.24

- C. Ensure the PWWI wiring is routed over the pad backplate, away from the rotor.

⚠ CAUTION

You must adjust the initial brake pad-to-rotor clearance or an inefficient, dragging brake can occur to prevent damage to components.

6. Set the initial brake pad-to-rotor running clearance. Refer to the procedure in this section.

Set the Initial Brake Pad-to-Rotor Running Clearance

⚠ CAUTION

Always set the initial brake pad-to-rotor running clearance with the air chamber installed to prevent damage to components.

1. Remove the adjuster cover. Figure 4.25.




Figure 4.25

2. Use a 10 mm wrench to rotate the manual adjuster stem **CLOCKWISE** so that the brake pad-to-rotor clearance is **ZERO**. Figure 4.26.




Figure 4.26

3. Deadadjust the manual adjuster stem one half turn **COUNTERCLOCKWISE** to set the initial running clearance. Reinstall the adjuster cover. Figure 4.26.

Hazard Alert Messages

Read and observe all Warning and Caution hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

⚠ WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving. Support the vehicle with safety stands. Do not work under a vehicle supported only by jacks. Jacks can slip and fall over. Serious personal injury and damage to components can result.

Before you service a spring chamber, carefully follow the manufacturer's instructions to compress and lock the spring to completely release the brake. Verify that no air pressure remains in the service chamber before you proceed. Sudden release of compressed air can cause serious personal injury and damage to components.

⚠ ASBESTOS AND NON-ASBESTOS FIBERS WARNING

Some brake linings contain asbestos fibers, a cancer and lung disease hazard. Some brake linings contain non-asbestos fibers, whose long-term effects to health are unknown. You must use caution when you handle both asbestos and non-asbestos materials.

Introduction

This section contains all the procedures required to completely disassemble the caliper. The disassembly procedures are presented in a specific sequence. If you are not completely disassembling the caliper, you will not be performing all the procedures in this section.

Remove the Caliper Assembly

1. If the caliper has a spring chamber, carefully cage and lock the spring. Follow the chamber manufacturer's instructions to completely release the brake. Use the correct wrench to remove the air chamber nuts and washers. Figure 5.1. Remove the air chamber assembly from the brake caliper and inspect the air chamber. Refer to Section 7.




Figure 5.1

2. Cover the exposed air chamber mounting aperture with tape to prevent debris from entering the caliper housing assembly. Figure 5.2.




Figure 5.2

3. Deadadjust the caliper and remove the brake pads. Refer to Section 4.
4. For both axial and radial mount carrier style brakes, use an appropriate size socket wrench (or if necessary, extension adapter MST225 5001 if available) to remove the carrier bolts and washers. Refer to Section 10. Figure 5.3 and Figure 5.4. Carefully remove the caliper assembly from the axle.

5 Caliper Components Replacement




Figure 5.3




Figure 5.4

Install the Caliper Assembly

1. Place the caliper assembly over the rotor.
2. Align the caliper carrier bolt holes. Assemble the caliper to the torque plate using the carrier bolts and correct washers. Special Nordlock washers are used only with the M16 mounting bolts. The M20 fasteners use standard hardened washers.

- **For radial mount brakes with M16 bolts:** Install two Nordlock washers onto each carrier bolt. The washers must be installed with the stepped surfaces facing each other and the fine line surfaces facing out. Figure 5.5 and Figure 5.6.




Figure 5.5




Figure 5.6

3. Use an appropriate size socket wrench (or extension adapter MST225 5001 if required), to tighten the carrier bolts to the torque values specified in Section 8. Figure 5.7. **T**

- **If you use the extension adapter:** The torque wrench and extension adapter must be aligned to achieve the correct torque.

5 Caliper Components Replacement




Figure 5.7

4. Check the caliper assembly to verify that it slides by hand.
5. Before you install the air chamber onto the caliper assembly, ensure the perforated transit plug is removed from the caliper chamber seal by pulling the tab. Figure 5.8 and Figure 5.9.




Figure 5.8




Figure 5.9

6. Install the air chamber onto the caliper assembly.
 - **For Meritor chambers:** Refer to Section 7.
 - **For non-Meritor chambers:** Refer to the manufacturer's instructions.
7. Install the pads and set the initial brake pad-to-rotor clearance. Refer to Section 4.

Replace the Adjuster Cover

1. Remove the adjuster cover from the caliper assembly. Figure 5.10.




Figure 5.10

2. Install the new adjuster cover. Verify that it is correctly located on the adjuster cover retaining ring.

Replace the Piston Boots

⚠ WARNING

Before you service a spring chamber, carefully follow the manufacturer's instructions to compress and lock the spring to completely release the brake. Verify that no air pressure remains in the service chamber before you proceed. Sudden release of compressed air can cause serious personal injury and damage to components.

1. If the caliper has a spring chamber, carefully cage and lock the spring. Follow the chamber manufacturer's instructions to completely release the brake.
2. Deadadjust the caliper and remove the brake pads. Refer to Section 4.

5 Caliper Components Replacement

- Use a 10 mm wrench to rotate the manual adjuster stem **CLOCKWISE** until the piston assemblies are extended approximately two-inches (50 mm). Figure 5.11 and Figure 5.12.




Figure 5.11




Figure 5.12

- Remove the piston boots. Do not remove the piston heads from the piston assembly.
- Use a suitable brake cleaner to clean the piston heads and housing.

- Check the condition of the piston shafts.
 - If excessive corrosion or wear is present:** Replace the caliper.
- Use the grease supplied in the kit to lightly lubricate the piston shafts. Only use the grease supplied with the replacement components and kits.

⚠ CAUTION

When you install the new piston boots, do not use grease to aid assembly. Your hands must be clean and free from grease. Using grease may result in damage to the piston boots.

- Carefully install a new piston boot over a piston head. The larger seal diameter with the tab goes over the piston head first. Do not install the piston boot bead into the housing assembly retaining groove at this time. Figure 5.13.




Figure 5.13

- Carefully install the piston boot into the piston head groove. Verify that the boot is correctly seated in the piston head groove. Figure 5.14.

5 Caliper Components Replacement




Figure 5.14



Figure 5.16

10. Use two fingers to stretch the piston boot and pull it over the housing assembly retainer groove. Figure 5.15.




Figure 5.15




Figure 5.17

11. Rotate the piston boot and verify that the piston boot beads are correctly seated in the retainer groove. Figure 5.16. The piston boot beads must be correctly seated. Figure 5.17 and Figure 5.18.

5 Caliper Components Replacement




Figure 5.18

12. Repeat the procedure to install the second piston boot.
13. Use a 10 mm wrench to rotate the manual adjuster stem COUNTERCLOCKWISE and deadadjust the piston assemblies. With the brake fully deadadjusted, it may be necessary to lift the piston boot tab and release air that may be inflating the boot. Figure 5.19.




Figure 5.19

14. Install the pads and set the initial brake pad-to-rotor running clearance. Refer to Section 4.
 - **If other caliper components must be replaced:** Replace the components before you install the pads and set the initial brake pad-to-rotor running clearance. Refer to the procedures in this section.

Remove the Caliper Bridge

This procedure is required to replace the following caliper components:

- Housing assembly
 - Slide pin boots
 - Slide pins
1. Remove the caliper assembly from the axle. Refer to the procedure in this section.
 - **If there is adequate room in the wheel well to service the caliper assembly:** You don't have to remove the caliper assembly from the axle.
 2. Use the correct size socket to remove the four bridge bolts. Figure 5.20. Discard the bridge bolts after they have been removed. They are no longer usable.




Figure 5.20

3. Carefully remove the bridge. Figure 5.21.
 - **If you are replacing the caliper housing assembly, slide pin boots or slide pins:** Proceed to the caliper housing assembly removal procedure in this section. Otherwise, proceed to the caliper bridge installation procedure in this section.

5 Caliper Components Replacement




Figure 5.21

Remove the Caliper Housing Assembly

⚠ WARNING

The caliper housing assembly is not serviceable. Do not attempt to tighten or loosen the eight piston housing bolts, which can cause the caliper to malfunction. Serious personal injury and damage to components can result.

1. Where applicable, Meritor recommends that you retain the visual wear indicator and spring in position before you remove the housing to prevent the load from ejecting the indicator as the housing is removed.
2. Ensure the visual wear indicator is not damaged. Figure 5.22.




Figure 5.22

3. Carefully remove the housing assembly from the slide pins. The assembly is not serviceable. Do not attempt to tighten or loosen the eight piston housing bolts. Figure 5.23.

- **If you are replacing the slide pin boots or slide pins:** Proceed to the slide pin boots removal procedure in this section. Otherwise, proceed to the caliper housing assembly installation procedure in this section.
- **If you are replacing the slide pin bushings or slide pin boot retainers:** Proceed to the slide pin bushing and slide pin boot retainer procedures in this section. Otherwise, proceed to the caliper housing assembly installation procedure in this section.




Figure 5.23

Remove the Slide Pin Boots

1. Remove the slide pin boots from the slide pins or the housing assembly retainers. Discard the slide pin boots.
 2. Clean and inspect the carrier for damage and wear. Pay particular attention to the pad abutment areas and slide pins. Figure 5.24.
- **If there is damage or excessive wear to the slide pins:** Replace the slide pins before proceeding. Refer to the procedure in this section.
 - **If there is excessive wear or damage to the carrier:** Replace the caliper assembly. Refer to the procedure in this section. Otherwise, proceed to the slide pin boots installation procedure in this section.

5 Caliper Components Replacement




Figure 5.24

Remove the Slide Pin Bushings

Axial and radial brakes incorporate a long and short slide pin arrangement. The long slide pin uses two round plastic bushings. Figure 5.25.




Figure 5.25

The short slide pin uses a single bronze oval bushing. Figure 5.26.




Figure 5.26

Before you remove the slide pin bushings, you must first remove the slide pin bushing end caps. If not already done so, carefully remove the end caps out from the slide pin bores. Figure 5.27.

⚠ CAUTION

Discard the end caps after removal. Always install new end caps during reassembly. Do not reinstall used end caps or damage to components can result.




Figure 5.27

To Remove the Round Plastic Slide Pin Bushings

NOTE: When you remove the round plastic slide pin bushings, the dust boot retainers which are pressed into the housing slide pin bores will be removed at the same time.

⚠ WARNING

Observe all warnings and cautions provided by the press manufacturer to avoid damage to components and serious personal injury.

Use a suitable driver and mallet or press to drive the bushing and dust boot retainer out of the housing. Figure 5.28.




Figure 5.28

5 Caliper Components Replacement

To Remove the Oval Slide Pin Bushings

NOTE: Due to the presence of a lip shown in Figure 5.29, the oval bushings must be removed in the opposite direction of the round plastic bushings.




Figure 5.29

1. Remove the slide pin boot retainer from the bushing bore. Figure 5.30.




Figure 5.30

NOTE: When you install new slide pin bushings, it is important to ensure correct alignment. The notches in the bushing are aligned horizontal between the two slide pin bushing bores.

2. Before removal, check the alignment of the oval bushings and mark the housing so that the new bushings can be correctly aligned when installed. Figure 5.31 and Figure 5.32.




Figure 5.31




Figure 5.32

3. Use Meritor tool MST 1000 to drive out the bushing from the housing. Figure 5.33. Refer to Section 10 for tool details. The bushing must be pushed out in the direction of the end cap side of the bore. Figure 5.34.




Figure 5.33

5 Caliper Components Replacement




Figure 5.34

Install the Slide Pin Bushings

Clean and Inspect the Slide Pin Bushing Bores

1. Before you install the bushings, clean the slide pin bushing bores with a suitable brake cleaner.
2. Inspect the slide pin bushing bores for excessive wear, corrosion or damage.
 - **If you find excessive wear, corrosion or damage:**
Replace the housing assembly.

To Install the Round Plastic Slide Pin Bushings

1. Place one of the new bushings onto a suitable driver from Meritor tool MST 1000.
2. Insert the bushing into the housing bore from the slide pin boot retainer side of the bore. Figure 5.35.




Figure 5.35

⚠ CAUTION

Do not apply excessive force when you pull the bushing into the housing or damage to the bushing can result.

3. Using the applicable parts from Meritor tool MST 1000, pull the bushing into the slide pin bore to a depth of 0.283-0.299-inch (7.2-7.6 mm) measured from the end face of the housing (on the boot retainer side of the bore). Figure 5.36.




Figure 5.36

4. Repeat Steps 1-3 to install the second bushing, but insert the bushing from the end cap side of the bore. To confirm the correct position for the second bushing, measure the distance from the same end face of the housing (on the boot retainer side of the bore) to the bottom of the second bushing. The measurement should be 3.299-3.315-inches (83.8-84.2 mm). Figure 5.37.




Figure 5.37

To Install the Boot Retainers for Round Slide Pins

1. Place the retainer onto a suitable driver from Meritor tool MST 1000. Figure 5.38.

5 Caliper Components Replacement




Figure 5.38

2. Place the retainer onto the housing.

⚠ CAUTION

Do not apply excessive force when you pull the retainer into the bore or damage to the bushing or retainer can result.

3. Use the applicable parts of Meritor tool MST 1000 to draw the retainer into the slide pin bore until the flat face of the retainer is 0.183-0.202-inch (4.65-5.15 mm) from the end of the slide pin bore. Figure 5.39.




Figure 5.39

To Install the Oval Slide Pin Bushings

NOTE: The bushing must be assembled from the actuator side of the housing.

1. Align the new oval bronze bushing with the markings made on the housing previously. Figure 5.40.




Figure 5.40

2. Place a suitable driver from Meritor tool MST 1000 onto the bushing and install the bushing into the housing bore. Figure 5.41.




Figure 5.41

⚠ CAUTION

Do not use a drift to install the bushing. A drift can damage the edge and prevent correct fit of the slide pin.

3. Use the applicable parts of Meritor tool MST 1000 to pull the bushing into the slide pin bore to a depth of 0.362-0.378-inch (9.2-9.6 mm) from the end of the slide pin boot retainer side of the bore. Figure 5.42 and Figure 5.43.

5 Caliper Components Replacement




Figure 5.42




Figure 5.43

To Install the Boot Retainers for Oval Slide Pins

1. Place the retainer onto a suitable driver from Meritor tool MST 1000. Figure 5.44.




Figure 5.44

2. Place the retainer onto the housing.

⚠ CAUTION

Do not apply excessive force when you pull the retainer into the bore or damage to the bushing or retainer can result.

3. Use the applicable parts of Meritor tool MST 1000 to draw the retainer into the slide pin bore until the flat face of the retainer is 0.183-0.202-inch (4.65-5.15 mm) from the end of the slide pin bore. Figure 5.45.




Figure 5.45

Replace the Slide Pins

1. Before you remove the slide pins, note the locations of the long and short slide pins. Remove the slide pin bolts retaining the slide pins to the carrier. Figure 5.46. If necessary, carefully release the slide pins from their location on the carrier using a rubber or soft metal hammer.




Figure 5.46

2. Clean the slide pin contact areas and the threaded holes in the carrier. Check for wear.

5 Caliper Components Replacement

- **If the carrier requires replacement:** Remove it from the axle and replace it with a new caliper. Refer to the procedure in this section.
3. To ensure correct function of the caliper, the long and short slide pins must be correctly located and installed onto the carrier. The long slide pin and short slide pin need no alignment. Locate the new slide pin positions on the carrier and secure with the corresponding slide pin bolts. Tighten the bolts to 310-332 lb-ft (420-450 N•m). 

Install the Slide Pin Boots

1. Use the grease provided in the kit to lightly lubricate the slide pins and the inside of the new slide pin boots. You must use the grease supplied with the replacement components and kits. Do not use any other type of grease.
2. Slide the new slide pin boots over the slide pins. Verify that the slide pin boot bead is in the slide pin retainer groove. Figure 5.47 and Figure 5.48.




Figure 5.47




Figure 5.48

3. Proceed to the caliper housing assembly installation procedure in this section.

Install the Caliper Housing Assembly

1. Apply grease to the slide pins and slide bores in the housing assembly. Figure 5.49 and Figure 5.50.




Figure 5.49




Figure 5.50

2. Carefully slide the housing assembly onto the slide pins. Be careful not to damage the slide pin boots when you install the housing assembly onto the slide pins. Figure 5.51.

5 Caliper Components Replacement




Figure 5.51

3. Install the slide pin boot beads into the housing retainer grooves. Figure 5.52 and Figure 5.53.




Figure 5.52




Figure 5.53

4. Verify that the slide pin boots are correctly located on both the carrier and housing retainers. Figure 5.54.




Figure 5.54

⚠ WARNING

Use a brass or synthetic mallet for assembly and disassembly procedures. Do not hit steel parts with a steel hammer. Pieces of a part can break off. Serious personal injury and damage to components can result.

5. For current EX225L2, H4, H6 and older revision of EX225H2 and H3 manufacturing prior to 9/14/2010.

If you are installing a new housing, use a copper-faced mallet to carefully tap one of the new end caps into the caliper housing assembly until it retains itself. Use the correct size tool to tap the end cap into the bore 0.069-0.088-inch (1.75-2.25 mm) for the short slide pin side, Figure 5.55, and 0.228-0.251-inch (5.8-6.4 mm) for the long slide pin side, Figure 5.56. The caps must be installed to the correct depth.

For the new revision of EX225H2 and H3 manufactured after 9/14/2010. If you are installing a new housing, use a copper-faced mallet to carefully tap one of the new end caps into the caliper assembly until it retains itself. Use the correct size tool to tap the end caps into the bore 0.069-0.088-inch (1.75-2.25 mm) for the short slide pin side, Figure 5.55, and 0.069-0.088-inch (1.75-2.25 mm) for the long slide pins Figure 5.56. The caps must be installed to the correct depth.

- **If the cap is pressed into the bore below the minimum dimension:** The full movement of the housing assembly will be restricted.

5 Caliper Components Replacement




Figure 5.55




Figure 5.57




Figure 5.56

6. Check the housing assembly to verify that it slides by hand on the slide pins. Take care not to trap your fingers while you check the sliding action of the housing assembly. Slide the housing assembly back and forth several times to check for smooth movement on the slide pins. The boots are correctly installed if they collapse from the pressure changes within the slide pin mechanism. Figure 5.57.

7. Proceed to the caliper bridge installation procedure in this section.

Install the Caliper Bridge

1. Position the bridge against the caliper housing assembly. Figure 5.58.




Figure 5.58

5 Caliper Components Replacement

⚠ WARNING

When you install the caliper bridge, always use new bridge bolts. Discard bridge bolts that were removed. Do not reuse bridge bolts, which can weaken under operating stress and may not tighten correctly. Sudden loss of braking performance, serious personal injury and damage to components can result.

2. Support the bridge in position. Install the four new bridge bolts. Do not reuse the bolts that were removed. Tighten the bolts to the torque specified in Section 8. Figure 5.59. If necessary, install the caliper assembly onto the axle. Refer to the procedure in this section.

- **If you are using M16 torx-head bridge bolts:** The preferred tightening method is “torque and angle”.

An alternative method is “torque only”. Before you proceed, follow these instructions.

- A. Inspect the bridge bolts to ensure they are not damaged or corroded.
- B. The bridge bolts should thread into the hole with minimal torque, ideally by hand.
- C. The bridge bolts must be dry. Check for grease or oil on the threads or under the bolt head.




Figure 5.59

3. Remove the clip/retainer from the visual wear indicator where applicable. Figure 5.60.




Figure 5.60

Hazard Alert Messages

Read and observe all Warning and Caution hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

⚠ WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving. Support the vehicle with safety stands. Do not work under a vehicle supported only by jacks. Jacks can slip and fall over. Serious personal injury and damage to components can result.

Inspection

1. Wear safe eye protection. Park the vehicle on a level surface. Block the wheels to prevent the vehicle from moving.
2. Use a jack to raise the vehicle so that the wheels to be serviced are off the ground. Support the vehicle with safety stands.
3. With the pads removed, rotate the wheel and inspect the hub and rotor assembly for damage.
4. Inspect both sides of the rotor for cracks and heat checks. Replace the hub, rotor or entire assembly, if necessary.
5. Check the hub and rotor assembly for damaged, loose or missing fasteners. For the correct torque, refer to Section 8.

Cracks

⚠ WARNING

Always replace a cracked rotor to avoid serious personal injury and damage to components.

When the crack extends through a section of the rotor, replace the rotor. Figure 6.1.




Figure 6.1

Heat Checking

Heat checks are short, thin, sometimes numerous, radial interruptions of the rotor braking surfaces. They are the result of disc brake operation. They are caused by the heating and cooling that occurs as the brakes are applied time after time. Heat checks will frequently wear away and reform, or they may become braking surface cracks, depending on such factors as the lining and rotor wear rate, brake balance, and how hard the brakes are used. There are two kinds of heat checking: light and heavy. Figure 6.2.




Figure 6.2

6 Rotor

Light Heat Checking

Cracks on the surface of the rotor that result from light heat checking are small and fine and do not require rotor replacement. Figure 6.2 and Figure 6.3.




Figure 6.3

Heavy Heat Checking

Heavy heat checking is surface cracks that have width and depth. Replace the rotor if the heat checks have a width greater than 0.02-inch (0.5 mm), depth greater than 0.04-inch (1 mm) and extend across the surface more than 75% in the radial direction. Figure 6.4.




Figure 6.4

Deep Grooves or Scores

Inspect both sides of the rotor. If you find grooves or scores of a depth less than 0.02-inch (0.5 mm), continue to use the rotor. If the grooves are greater than 0.02-inch (0.5 mm), you may choose to resurface the rotor. If the rotor thickness measured across any groove is less than the minimum discard thickness found on the rotor casting, discard and replace the rotor. Figure 6.5.




Figure 6.5

Blue Marks or Bands

Blue marks or bands indicate that the rotor was very hot. Determine the cause and correct the conditions. Figure 6.6.




Figure 6.6

Measure the Rotor Thickness

⚠ CAUTION

Replace the rotor if it reaches the minimum allowable rotor thickness found on the rotor casting. Damage to components can result.

1. Use a micrometer to measure the rotor thickness. If you are replacing the brake pads, the rotor should be replaced if the rotor thickness is less than the minimum discard thickness found on the rotor casting. Figure 6.7.




Figure 6.7

2. Check for uneven rotor wear. Using the pad retainer as a gauge, place it between the rotor surface and carrier pad abutment. Check both the inboard and outboard sides of the rotor. Figure 6.8 and Figure 6.9.

- **If the pad retainer fits into the gap on either side:**
Replace the rotor.




Figure 6.8




Figure 6.9

Measure the Rotor Runout

1. Attach a dial indicator to the caliper or axle frame.
2. Check the lateral runout of the rotor braking surface. The runout measurement should be taken from the center of the rotor braking surface. The end play of the hub bearings should not be included in this measurement. The runout should not exceed 0.02-inch (0.5 mm) through one full revolution of the rotor.
 - **If the runout is greater than 0.02-inch (0.5 mm):** Check the wheel bearings for correct adjustment. Refer to the manufacturer's instructions.

6 Rotor

Removal and Installation

Replace the Rotor

1. Remove the caliper. Refer to Section 5.
2. Remove the hub and rotor assembly. Refer to the axle manufacturer's service manual.
3. Use the correct size socket wrench to remove the hub-to-rotor bolts and washers. Refer to Section 8. Remove the rotor from the hub.
4. Verify that the hub and rotor mating surfaces are clean and free of debris or burrs. Verify that the hub rotor pilots are correctly engaged to the rotor.

⚠ WARNING

Use the correct fasteners and washers. Incorrect fasteners and washers may result in an insufficient clamping load or damage to the caliper or wheel. Serious personal injury and damage to components can result.

Take care when you use Loctite[®] adhesive to avoid serious personal injury. Read the manufacturer's instructions before using this product. Follow the instructions carefully to prevent irritation to the eyes and skin.

5. Apply Loctite[®] 620 retaining compound to the new hub-to-rotor bolts.
6. Use the new hub-to-rotor bolts and washers to attach the new rotor to the hub. Be careful not to damage or move the hub-mounted tone rings during new rotor installation.
7. Tighten the hub-to-rotor bolts in a crisscross pattern to the correct torque. Refer to Section 8. Figure 6.10 or Figure 6.11.




Figure 6.10




Figure 6.11

8. Ensure that all bolt heads do not protrude past the wheel-to-hub mounting surface.
9. Install the hub and rotor assembly to the axle. Refer to the axle manufacturer's service manual. Ensure that the rotor braking surfaces are free of oil, grease and other contaminants.
10. Install the caliper assembly and brake pads. Adjust the brake pad-to-rotor clearance. Refer to Section 5.

Hazard Alert Messages

Read and observe all Warning and Caution hazard alert messages in this publication. They provide information that can help prevent serious personal injury, damage to components, or both.

⚠ WARNING

To prevent serious eye injury, always wear safe eye protection when you perform vehicle maintenance or service.

Before you service a spring chamber, carefully follow the manufacturer's instructions to compress and lock the spring to completely release the brake. Verify that no air pressure remains in the service chamber before you proceed. Sudden release of compressed air can cause serious personal injury and damage to components.

Introduction

The DiscPlus™ EX225 air disc brake uses a 0.59-inch (15 mm) chamber piston standout length. Figure 7.1. The air chamber part number is located on a nameplate.

⚠ WARNING

Always install an air chamber with the correct chamber piston length. If an incorrect air chamber is installed, the difference in chamber piston length will result in partial brake application. Serious personal injury and damage to components can result.




Figure 7.1

Inspection

When removing service brake chambers, if there is no spring brake chamber to cage, carefully remove the service brake chamber from the caliper and proceed to the inspection procedure. If the caliper has a spring chamber, carefully cage and lock the spring prior to removing from the caliper and performing the inspection procedure. Follow the chamber manufacturer's instructions to completely release the brake.

1. With the air chamber removed, visually inspect the chamber mounting studs. Figure 7.2.
 - **If there are signs of uneven wear, broken, loose or missing studs:** Replace the chamber.




Figure 7.2

2. Visually inspect the chamber push rod and chamber seal. Figure 7.2.
 - **If there is damage:** Replace the chamber.
3. Visually inspect the chamber piston, chamber seal and chamber-mounting aperture on the caliper housing assembly. Figure 7.2 and Figure 7.3.
 - **If signs of water entry and corrosion are present:** Replace the chamber and caliper assembly.

7 Air Chamber




Figure 7.3




Figure 7.5

Installation

Spring or Service Brake Chamber

When installing service brake chambers, if there is no spring brake chamber to cage, proceed to the installation procedure. If the caliper has a spring chamber, carefully cage and lock the spring. Follow the chamber manufacturer's instructions completely to release the brake. Typically, new spring brake chambers are shipped caged.

1. Verify that the chamber seal is well seated, free of debris and shows no signs of damage. Do not install a brake chamber that shows signs of debris or excess flash on the seal.
2. Verify that the caliper seal surface and the mounting surface are free of oil, grease and debris and show no signs of damage.
3. Before you install the air chamber onto the caliper assembly, ensure the perforated transit plug is removed from the caliper chamber seal by pulling the tab. Figure 7.4 and Figure 7.5.




Figure 7.4

4. Position the chamber onto the caliper. Determine which of the two possible brake chamber orientations places the ports in the most accessible position.
5. As you position the chamber onto the caliper, visually check that the chamber push rod is nesting in the pocket of the operating shaft.
6. Firmly hold the chamber onto the caliper by hand. Place the two washers and nuts onto the mounting studs. Do not work from behind the spring brakes, always work from the side and front. Spring brake chambers are under more than 2,000 pounds (8900 N) of spring force.
7. Use a 24 mm wrench to tighten the nuts in an alternating sequence.
 - A. Tighten the nuts until the mating surfaces meet. Use minimal torque on the two nuts.
 - B. Use a torque wrench to tighten each nut to 59-75 lb-ft (80-100 N•m). Then, use a torque wrench to tighten each nut to 133-155 lb-ft (180-210 N•m). 
8. If breather plugs are supplied, locate the bottommost breather plug and remove it from the chamber. Figure 7.6 and Figure 7.7.




Figure 7.6




Figure 7.7

9. Install the air hoses to the chamber ports. Refer to the manufacturer's instructions.
10. If the caliper has a spring chamber, carefully uncage and unlock the spring. Follow the chamber manufacturer's instructions.

8 Specifications

Lining Wear Limits

0.012-inch (3 mm) remaining lining thickness

Torque Specifications

Description	Fastener Size	Wrench Size	lb-ft	N•m
Pad Retainer Bolt	M10	17 mm	25-30	34-40
Carrier Bolt on Axial Mount Carrier	M20	30 mm	350-450*	474-610
Carrier Bolt on Radial Mount Carrier	M16	24 mm	205-235	277-318
	M20 Internal Head	17 mm	350-450	474-610
Bridge Bolt	M14 Torx Head	E18	174-202	235-275
Bridge Bolt	M16 Internal Head	14 mm	221-253	300-350
Bridge Bolt	M16 Torx Head	E20	Torque and Angle (Recommended)	
			70-77	95-105
			+75 degrees +/- 5 degrees	+75 degrees +/- 5 degrees
			Torque Only	
			211-217	285-295
Slide Pin Bolts	M18 Torx Head	T80	310-332	420-450
Hub-to-Rotor Bolt	5/8-inch	15/16-inch	155-195	210-264
Hub-to-Rotor Bolt	M16	24 mm	165-190	224-257
Air Chamber Nut, Initial	M16	24 mm	59-75	80-100
Air Chamber Nut, Final	M16	24 mm	133-155	180-210

*Torque wrench setting must be altered when using service tool MST225 5001.

Torque Wrench Setting Using Extension Adapter MST225 5001 (ADB225 Wrench)

Extension adapter MST225 5001 (ADB225 Wrench) is a service tool designed to provide easier access to the axial type ADB carrier-to-torque plate bolts. When using this extension adapter, the torque wrench setting must be altered to obtain accurate tightening of the carrier-to-torque plate bolts. Refer to Section 10 for an illustration of the tool, Figure 8.1, and the following table for the altered torque wrench setting.




Figure 8.1

Description	lb-ft	N•m
Carrier Bolt Standard Torque Wrench Setting	450	610
2-Foot Torque Wrench Setting with 7-inch Extension Adapter	348	472
3-Foot Torque Wrench Setting with 7-inch Extension Adapter	377	511
4-Foot Torque Wrench Setting with 7-inch Extension Adapter	392	531
5-Foot Torque Wrench Setting with 7-inch Extension Adapter	402	545

9 Diagnostics

Troubleshooting

Air Disc Brake

Conditions	Possible Causes	Check For	Corrections
Brake drag	Incorrect initial adjustment	Correct pad-to-rotor clearance	Readjust to set the correct rotor-to-pad clearance.
	Incorrect pad-to-rotor clearance		
	Spring or service brake not releasing	Correct operation of air system or air chamber	Refer to the vehicle manufacturer's instructions. Repair or replace parts as required.
	Vehicle air system malfunction		
Short brake pad lining life	Brake not releasing	Damaged slide pin boots, caliper should move back and forth by hand with linings removed	Replace the caliper assembly.
	Air line too short	Water entry or seized operation shaft, internal	Replace the caliper assembly and air chamber.
		Correct air line length	Replace the air line. Refer to the vehicle manufacturer's instructions.
	Refer to Brake drag.	Refer to Brake drag.	Refer to Brake drag.
Smoking brakes	Caliper seized or sticking on slide pins	Damaged slide pin boots, caliper should move back and forth by hand with linings removed	Replace the caliper assembly.
	Damaged rotor surface	Cracks or heavy heat checking	Refer to Section 6.
	Vehicle overload	Refer to the weight limitations on the vehicle identification plate.	Observe the vehicle manufacturer's load recommendations.
	Companion brakes do not work correctly	Inspect the companion vehicle brakes and air system.	Adjust or repair as required.
Smoking brakes	Abrasive environment	Contamination on the brake pad and rotor surface	Install pad or rotor shields where available.
	High brake temperature	Refer to Brake drag and Short brake pad lining life.	Refer to Brake drag and Short brake pad lining life. Can be a temporary situation with new or low mileage pads.
	Contamination on the linings or rotor	Grease, oil, undercoating, paint, etc., on the linings or rotor	<ul style="list-style-type: none"> Inspect the hub seal. Replace as required. Clean the rotor and caliper assembly. Replace the pads.

Conditions	Possible Causes	Check For	Corrections
Poor stopping power <ul style="list-style-type: none"> • Long stopping distances • Poor driver feel • High brake pressures • Vehicle pulls to one side 	Vehicle air system malfunction	Correct air pressure at the chamber inlet	Have the air system evaluated by a qualified brake system specialist.
	Contamination on the linings or rotor	Grease, oil, undercoating, paint, etc., on the linings or rotor	<ul style="list-style-type: none"> • Inspect the hub seal. Replace as required. • Clean the rotor and caliper assembly. • Replace the pads.
	Brakes out-of-adjustment	Excessive pad-to-rotor clearance	Readjust to set the correct pad-to-rotor clearance.
	Vehicle overload	Refer to the weight limitations on the vehicle identification plate.	Observe the vehicle manufacturer's load recommendations.
	Companion brakes not working correctly	Inspect the companion vehicle brakes and air system.	Adjust or repair as required.
	Incorrect pads installed	Refer to the vehicle manufacturer for the correct pads.	Replace the pads.
Brake noise	Incorrect pad installation	Friction material facing the rotor surface	Correct the pad installation. Replace the pads and rotor, if necessary.
	Brake pads not free to move in the caliper	Corrosion or debris on the pads or carrier abutments	Clean or replace the pads, if necessary. Clean the pad abutments on the carrier.
	Worn brake pads	Lining thickness	Replace the pads, if necessary.
	Brake component attachments are not installed to specification	Check for loose connections and fasteners.	Tighten the connections and fasteners to the specified torque.
	Rotor cracks or excessive runout	Excessive cracking, heat checking or runout	Refer to Section 6.
	Pad spring damaged or not installed	Correct pad spring installation	Install the pad springs.
	Incorrect pads installed	Refer to the vehicle manufacturer for the correct pads.	Replace the pads.
	Bent or loose pad retainer	Bent pad retainer or loose pad retainer bolt	Replace or tighten the pad retainer.

10 Special Tools

MST 1000, Bushing Service Tool

To obtain this tool, call Meritor's Commercial Vehicle Aftermarket at 888-725-9355.




Figure 10.1

MST225 5001, ADB225 Wrench (Extension Adapter)

To obtain this tool, call Meritor's Commercial Vehicle Aftermarket at 888-725-9355. Refer to Section 8 for altered torque settings when using this tool.




Figure 10.2

Meritor Heavy Vehicle Systems, LLC

2135 West Maple Road

Troy, MI 48084 USA

866-OnTrac1 (668-7221)

meritor.com

Copyright 2013
Meritor, Inc.

Printed in USA

Revised 02-13
Maintenance Manual MM-0467 (16579)

